

Linksys SPA942

Sumario

- 1 Configuración dunha IP estática
- 2 Ver a Configuración Avanzada
- 3 Obter información do estado do teléfono
- 4 Configuración do Panel do teléfono e do número de liñas
- 5 Configuración das Extensións do teléfono

Configuración dunha IP estática



1. Pulsar no botón **Setup**.
2. Pulsar o número **9** ou navegar ata a opción **Network**.
3. No apartado **1 WAN Connection Type**, pulsar no botón **Edit** e pulsar o botón **option** ata que apareza a opción **Static IP**. Logo pulsar **OK**.
4. Logo ir ao apartado **Non-DHCP IP Address**. Pulsar en **Edit**, e configurarlle a IP estática do teléfono. Empregar a tecla asterisco (*) en vez de (.). Por exemplo, a dirección IP 10.200.100.1 será escrita como 10*200*100*1. Logo pulsa en **OK**.
5. Ir ao apartado **9 Non-DHCP Subnet Mask**. Pulsar no botón **Edit**, entón introducir a máscara de subrede do teléfono. Pulsar o botón **OK**.
6. No apartado **10 Non-DHCP Default Route**. Pulsar o botón **Edit**, e introducir a porta de enlace por defecto do teléfono IP. Logo pulsar **OK**.
7. Ir ao apartado **11 Non-DHCP DNS 1**. Pulsar o botón **Edit**, e introducir o servidor DNS1 para o teléfono. Pulsar **OK**.
8. Se fose necesario, ir ao apartado **12 Non-DHCP DNS 2** para configurarlle o servidor DNS2.
9. Logo escoller a opción **Save** para grabar todo o configurado.
10. Por último, acceder ao apartado **12 Reboot** e reiniciar o Teléfono.

Unha vez configurada a IP do Teléfono SIP podemos entrar na súa web de configuración dende calquera navegador: <http://10.200.100.1>

Unha vez aí podemos cambiar, se queremos, a súa configuración web:

Info | System | Phone | User

[Admin Login](#) | [basic](#) | [advanced](#)
[Personal Directory](#) | [Call History](#)

System Information

DHCP:	Static IP	Current IP:	10.200.100.1
Host Name:	SipuraSPA	Domain:	
Current Netmask:	255.255.0.0	Current Gateway:	10.200.0.254
Primary DNS:	10.0.0.36		
Secondary DNS:	10.0.0.35		

Product Information

Product Name:	SPA-942	Serial Number:	4LO00HB09177
Software Version:	6.1.3(a)	Hardware Version:	1.0.3(524f)
MAC Address:	000E08D456A7	Client Certificate:	Installed
Customization:	Open	Licenses:	None

Phone Status

Current Time:	6/1/2009 16:40:47	Elapsed Time:	08:45:22
Broadcast Pkts Sent:	0	Broadcast Bytes Sent:	0
Broadcast Pkts Recv:	40377	Broadcast Bytes Recv:	4092324
Broadcast Pkts Dropped:	0	Broadcast Bytes Dropped:	0
RTP Packets Sent:	4504	RTP Bytes Sent:	720640
RTP Packets Recv:	4470	RTP Bytes Recv:	715200
SIP Messages Sent:	554	SIP Bytes Sent:	243563
SIP Messages Recv:	553	SIP Bytes Recv:	298564
External IP:		Operational VLAN ID:	n/a

Ver a Configuración Avanzada

Se queremos ver a configuración avanzada para configurar completamente o teléfono hai que pulsar en "Admin login":



Obter información do estado do teléfono

Tamén podemos obter información do estado da configuración:



A Division of Cisco Systems, Inc.

Linksys Telephone Configuration

[User Login](#) | [basic](#) | [advanced](#)
[Personal Directory](#) | [Call History](#)

Info | [System](#) | [SIP](#) | [Regional](#) | [Phone](#) | [Ext 1](#) | [Ext 2](#) | [Ext 3](#) | [Ext 4](#) | [User](#)

System Information

DHCP:	Static IP	Current IP:	10.200.100.1
Host Name:	SipuraSPA	Domain:	
Current Netmask:	255.255.0.0	Current Gateway:	10.200.0.254
Primary DNS:	10.0.0.36		
Secondary DNS:	10.0.0.35		

Product Information

Product Name:	SPA-942	Serial Number:	4LO00HB09177
Software Version:	6.1.3(a)	Hardware Version:	1.0.3(524f)
MAC Address:	000E08D456A7	Client Certificate:	Installed
Customization:	Open	Licenses:	None

Phone Status

Current Time:	6/1/2009 16:50:00	Elapsed Time:	08:54:35
Broadcast Pkts Sent:	0	Broadcast Bytes Sent:	0
Broadcast Pkts Recv:	41014	Broadcast Bytes Recv:	4155669
Broadcast Pkts Dropped:	0	Broadcast Bytes Dropped:	0
RTP Packets Sent:	4504	RTP Bytes Sent:	720640
RTP Packets Recv:	4470	RTP Bytes Recv:	715200
SIP Messages Sent:	564	SIP Bytes Sent:	247813
SIP Messages Recv:	563	SIP Bytes Recv:	303954
External IP:		Operational VLAN ID:	n/a

Configuración do Panel do teléfono e do número de liñas

No apartado "Phone" poderemos configurar certos parámetros interesantes do teléfono:

- En "General" configuramos o nome do teléfono e o título ou imaxe que queremos apareza no seu panel.
- Cada liña do teléfono que nos interese debemos adxudicarlle a unha extensión; no noso caso empregaremos só unha liña das catro posibles, as outras poñerémolas en "Disabled".



A Division of Cisco Systems, Inc.

Linksys Telephone Configuration

[Info](#) | [System](#) | [SIP](#) | [Regional](#) | **Phone** | [Ext 1](#) | [Ext 2](#) | [Ext 3](#) | [Ext 4](#) | [User](#)

[User Login](#) | [basic](#) | [advanced](#)
[Personal Directory](#) | [Call History](#)

General

Station Name:	<input type="text" value="Informatica"/>	Voice Mail Number:	<input type="text" value="8000"/>
Text Logo:	<input type="text" value="Grupo%0ATraballo VoI"/>		
BMP Picture Download URL:	<input type="text"/>		
Select Logo:	<input type="text" value="Text Logo"/> ▼	Select Background Picture:	<input type="text" value="Text Logo"/> ▼
Screen Saver Enable:	<input type="text" value="no"/> ▼	Screen Saver Wait:	<input type="text" value="300"/>
Screen Saver Icon:	<input type="text" value="Background Picture"/> ▼		

Line Key 1

Extension:	<input type="text" value="1"/> ▼	Short Name:	<input type="text" value="\$USER"/>
------------	----------------------------------	-------------	-------------------------------------

Line Key 2

Extension:	<input type="text" value="Disabled"/> ▼	Short Name:	<input type="text" value="\$USER"/>
------------	---	-------------	-------------------------------------

Line Key 3

Extension:	<input type="text" value="Disabled"/> ▼	Short Name:	<input type="text" value="\$USER"/>
------------	---	-------------	-------------------------------------

Line Key 4

Extension:	<input type="text" value="Disabled"/> ▼	Short Name:	<input type="text" value="\$USER"/>
------------	---	-------------	-------------------------------------

Line Key Extended Function

Subscribe Expires:	<input type="text" value="1800"/>	Subscribe Retry Interval:	<input type="text" value="30"/>
Subscribe Delay:	<input type="text" value="1"/>	SPA932 Call Pickup Code:	<input type="text" value="*98"/>
SCA Line ID Mapping:	<input type="text" value="Vertical First"/> ▼	ACD Ext:	<input type="text" value="1"/> ▼

Configuración das Extensións do teléfono

O SPA 942 ten catro liñas posibles pero só empregamos unha delas, que foi a que se enlazou á "Extensión 1" no apartado anterior, a configuración da Extensión faise tal e como se ve na seguinte imaxe:



A Division of Cisco Systems, Inc.

Linksys Telephone Configuration

[Info](#) | [System](#) | [SIP](#) | [Regional](#) | [Phone](#) | **Ext 1** | [Ext 2](#) | [Ext 3](#) | [Ext 4](#) | [User](#)

[User Login](#) | [basic](#) | [advanced](#)
[Personal Directory](#) | [Call History](#)

General

Line Enable: yes

NAT Settings

NAT Mapping Enable: no NAT Keep Alive Enable: no

SIP Settings

SIP Port: SIP Debug Option:

Call Feature Settings

Message Waiting: no Default Ring:

Mailbox ID:

Proxy and Registration

Proxy: Register: yes

Make Call Without Reg: no Register Expires:

Ans Call Without Reg: no

Subscriber Information

Display Name: User ID:

Password: Use Auth ID: no

Auth ID:

Audio Configuration

Preferred Codec: Use Pref Codec Only: no

Second Preferred Codec: Third Preferred Codec:

Silence Supp Enable: no DTMF Tx Method:

[User Login](#) | [basic](#) | [advanced](#)

Copyright © 1992-2006 Cisco Systems, Inc. All Rights Reserved.